

How to Use Epoxy Resin for Molds?

1 Working the resin for at least 3 minutes.

You do the same thing with the hardener before you mix it with the resin. Continue to work the mixture till you have a uniform consistency.

2

3 Pour the epoxy resin and hardener mixture into your mold, preferably thinly at first.

Add some beautifying features such as leaves, glitters, stars, and such objects.

4

5 You should add another layer of your epoxy resin and hardener mixture.

The possibility of having bubbles is high, you should heat the hardening resin with a heat gun to remove as many bubbles as possible. The resin melts and fills in the air pockets without compromising the mold.

6

7 Leave it to cure for at least 24 hours. Note that it should have hardened in about 10 hours, but it needs to cure. Ensure that it's protected from dust.

Remove the hardened resin from the mold and inspect the result of your work.

8

9 You should have a clear art, something like glass, that shows all the beautifying objects you added to it and takes the shape of the mold.